



OWNER'S MANUAL ADDENDUM 2

XDC-1 Multimedia Loudspeaker System

(formerly known as the Xducer 2.1)

For increased ease of use, we recommend adjusting overall playback levels with the volume control CLOSEST to the playback source, i.e. that of the playback source or the system's preamplifier or receiver. In this case, you should operate the XDC-1's SUBWOOFER VOLUME and MASTER VOLUME controls as "level controls" – adjusting during initial setup, and occasionally re-adjusting whenever the need arises for different overall levels or individual satellite and subwoofer levels.

However, for instances where no volume control is available, i.e. use with fixed-level sources (those with NO volume control, such as a CD/DVD Player, tape deck, VCR, etc.), or when you must use a tape output on your preamplifier or receiver, the XDC-1's MASTER VOLUME control can be used to adjust overall playback volume (see page 12).

Occasionally, the output of a fixed-level source will exceed the industry standard of 2 volts. These rare sources may increase the level of the MASTER VOLUME control's FIRST position above "minimum", meaning that listening at very low volumes may not be possible. **ATTENTION IPOD OWNERS: The "Line Out" connection on the Dock, qualifies as one of these higher output sources. However, the iPod's Headphone output works perfectly with the XDC-1. So to connect the iPod, simply use the headphone output located on the umbilical remote.**

As 95% of all available sources adhere to common industry practice, this will not be relevant to most users.